

Advisory Circular

AC 21-99(0)

Aircraft Wiring and Bonding

November 2005

CONTENTS

- 1. Wire and Cable
- 2. Identifying Wire and Cable
- 3. Preparing Wire and Cable
- 4 Electrical Wire Installation
- 5. Repairing Wire and Cable
- 6. Solderless Terminations and Splices
- 7. Soldering
- 8. Lacing and Tying
- 9. Wiring: Lock, Shear and Seal
- 10. General Purpose Connectors
- 11. Electric Connector Sealing Compound
- 12. RF Connectors and Cabling
- 13. Bonding and Grounding
- Earthing and Bonding of Aircraft and Ground Support Equipment
- Installation of Busbars, Junction Boxes, Protective Devices and Terminal Boards
- 16. Thermocouple Wire Soldering and Installation
- 17. Aged Aircraft Wiring
- 18. Aircraft Electrical System Inspection
- 19. Fibre Optics

REFERENCES

- * Civil Aviation Safety Regulations (CASR) Part 21.
- * TCA DO-160D: Environmental Conditions and Test Procedures for Airborne Equipment.
- * SAE Aerospace AS50881 Wiring Aerospace Vehicles.
- * Federal Aviation Administration; AC 43.13-1B: Acceptable Methods, Techniques and Practices
- Aircraft Inspection and Repair

PURPOSE

The purpose of this Advisory Circular is to provide guidance material for maintenance of aircraft electrical systems and bonding of aircraft.

STATUS OF THIS AC

This is the first issue of this Advisory Circular to be written on aircraft wiring and bonding procedures.

Advisory Circulars are intended to provide advice and guidance to illustrate a means, but not necessarily the only means, of complying with the Regulations, or to explain certain regulatory requirements by providing informative, interpretative and explanatory material. When an AC is referred to in a 'Note' below a regulation, the AC remains as guidance material. ACs should always be read in conjunction with the referenced regulations.

Approved
Neville Probert
General Manager
Manufacturing, Certification and New Technologies Office

Produced & distributed with permission from Australian Civil Aviation Safety Authority by:



Aircraft Technical Book Company PO Box 270 Tabernash, CO 80478 USA www.ACtechBooks.com 1-970 726-5111 fax 1-970 726-5115

ISBN 978-0-9838658-0-3

TABLE OF CONTENTS

| | | Page No | Para No |
|-----------|--|---|--|
| | List of Tables List of Figures | vii xi | |
| SECTION 1 | | | |
| CHAPTER 1 | INTRODUCTION | | |
| | General Purpose of Manual Scope Intended Use Arrangement of Material Revisions | 1 1 1 1 1 2 | 1 to 3 4 5 6 7 to 10 11 |
| SECTION 2 | | | |
| CHAPTER 1 | WIRE AND CABLE | | |
| | Introduction Reference Specifications Definitions Selection of Aircraft Electrical Wire and Cable MIL-DTL-16878 SAE-AS-81044 MIL-W-22759 MIL-DTL-25038 MIL-W-7072 NEMA WC 27500 MIL-DTL-81381 MIL-C-85485 Current Ratings of Wire and Maximum Allowable Nicked or Broken Strands Wire Gauge Comparison | 1 1 3 1A-1 1B-1 1C-1 1D-1 1E-1 1F-1 1G-1 1H-1 | 1 to 2 3 4 to 6 7 to 16 |
| CHAPTER 2 | IDENTIFYING WIRE AND CABLE Introduction | 1 | 1 to 2 |
| | Wire Identification Code (Basic) Wire and Component Identification Codes for | 1 | 3 to 26 |
| | Modification Identification Methods Marking Objectives Spacing of Wire Identification Location of Sleeve Marking Multi-conductor Cable Identification Coaxial Cable Identification Thermocouple Cable Identification Wire Identification at Terminal Boards and Enclosures Selection of Identification Sleeving Wire Marking Set-up of Marking Machine for Wire Stamping Set-up of Marking Machine for Sleeve Stamping | 3 6 6 6 6 6 7 7 7 7 7 7 | 27 to 28 29 30 31 32 33 to 34 35 36 37 38 39 to 40 41 42 |
| | Installing Identification Sleeves on Wiring Identification of Wire Bundles and Harnesses | 8 8 | 43 44 |

AC 21-99 Aircraft Wiring and Bonding Table of Contents

| CHAPTER 3 | PREPARING WIRE AND CABLE | | |
|-----------|---|---|--|
| | Introduction Cutting Wire and Cable Stripping Wire and Cable Tinning Wire and Cable Terminating Shielded Cable | 1 1 2 5 6 | 1 2 to 6 7 to 13 14 to 20 21 to 24 |
| CHAPTER 4 | ELECTRICAL WIRING INSTALLATION | | |
| | Introduction Reference Specifications Definitions Wire Types Wire Groups and Bundles Routing and Installation Conduit Metallic Conduit Non-metallic Conduit Heat-shrinkable Tubing Cable Clamps Connections to Terminal Boards and Busbars Installation of Wires in Conduit Installation of Connectors Installation of Wire in Junction Boxes Terminal Junction System | 1 1 2 2 2 5 8 8 9 9 13 18 25 26 28 28 | 1 2 3 4 5 to 14 15 to 32 33 to 34 35 to 39 40 41 to 46 47 to 59 60 to 76 77 to 79 80 to 85 86 to 88 89 to 102 |
| CHAPTER 5 | REPAIRING WIRE AND CABLE | | |
| | Introduction Single Wire Repair Multi-conductor Repair MIL-STD-1553 Data Bus Cable Repair | 1 1 3 8 | 1 2 to 3 4 to 6 7 to 21 |
| CHAPTER 6 | SOLDERLESS TERMINATIONS AND SPLICES | | |
| | Introduction Reference Specifications Description Terminating Small Copper Wires with Pre-insulated Terminal Lugs Terminating Large Copper Wires Crimping Procedure for MS25441 Tools Terminating Aluminium Wire Splicing Small Copper Wires Splicing Procedure for M81824 Environmental Splices Splicing High Temperature Wires Splicing Aluminium Wires Multi-splicing Environment Resistant Wire Disconnect Splices Splicing to Reduce Wire Size Inspection of Crimped Connections Terminal Junction Systems Terminations and Tooling Stud Size and Corresponding Terminal Lug Dimension Reference Chart Disconnect Splices and Tooling Crimp Tool Testing | 1 1 1 2 7 9 9 11 12 12 13 13 13 13 14 14 6A-1 6B-1 6C-1 6D-1 | 1 to 2 3 4 to 7 8 to 14 15 to 19 20 21 to 25 26 to 29 30 31 32 33 34 35 36 37 |

| CHAPTER 7 | SOLDERING | | |
|------------|---|----------|----------------------|
| | Introduction | 1 | 1 to 3 |
| | Reference Specifications and Standards | 1 | 4 |
| | Definitions and Descriptions Heat Application Methods | 1 3 | 5 to 11 12 to 15 |
| | Preparation and Maintenance of the Soldering | 3 | 12 (0 15 |
| | Iron | 3 | 16 to 20 |
| | Soldering Operation Inspecting a Finished Solder Joint | 4 6 | 21 to 37 38 to 40 |
| | Inspecting a Finished Solder John | O | 36 (0 40 |
| CHAPTER 8 | LACING AND TYING | | |
| | Introduction | 1 | 1 to 2 |
| | Reference Specifications | 1 | 3 |
| | Definitions Metarials | 1 1 | 4 to 7 |
| | Materials General Precautions | 2 | 8 to 10 11 |
| | Lacing | 3 | 12 to 15 |
| | Tying | 4 | 16 to 20 |
| | Self-clinching Cable Straps and Spiral Wrap | 5 | 21 to 30 |
| | Lacing and Tying in High Temperature Areas | 7 | 31 |
| CHAPTER 9 | WIRING: LOCK, SHEAR AND SEAL | | |
| | Introduction | 1 | 1 to 2 |
| | Reference Specifications | 1 | 3 |
| | Definitions | 1 | 4 to 7 |
| | General Procedures for Lock, Shear and Seal | 4 | 0 to 12 |
| | Wiring Specific Procedures for Lock, Shear and Seal | 1 | 8 to 13 |
| | Wiring | 3 | 14 to 21 |
| CHAPTER 10 | GENERAL PURPOSE CONNECTORS | | |
| | Introduction | 1 | 1 to 3 |
| | Reference Specifications | 1 | 4 |
| | Description | 2 | 5 to 11 |
| | Insulating Sleeves and Heat-shrinkable Tubing | 4 | 12 to 14 |
| | Soldering Procedure | 5 | 15 to 26 |
| | Crimp Contacts | 10 | 27 to 28 |
| | Hand Crimping Tools for Connector Contacts Tool Inspection Gauging | 11 11 | 29 to 33 34 to 35 |
| | Types of Contact Positioning Devices | 22 | 36 to 39 |
| | Crimping Procedures | 22 | 40 to 42 |
| | Crimping Tool Kits | 25 | 43 |
| | Installing and Removing Crimp Type Contacts | 25 | 44 to 49 |
| | Shield Connections | 33 | 50 to 55 |
| | Continuity Test | 35 36 | 56 to 57 |
| | Test Leads Protection of Electrical Connectors | 36 36 | 58 59 to 61 |
| | Potting Connectors | 38 | 62 |
| | Connector Accessories | 41 | 63 to 72 |
| | Boot Repair Procedures | 47 | 73 to 77 |
| | Rectangular Connectors | 48 | 78 to 79 |
| | MIL-DTL-83723 Circular Connectors | 48 52 | 80 to 84 |
| | MIL-DTL-5015 Connectors MIL-C-26482, MIL-C-26500 and MIL-C-81703 | 52 | 85 to 86 |
| | Connectors | 57 | 87 to 88 |
| | MIL-C-81511 Connectors | 58 | 89 to 94 |
| | MIL-DTL-38999 Connectors | 65 | 95 to 97 |
| | M and MS Connector Cable Clamps | 70 | 98 |
| | MIL-C-81659 Connectors | 73 | 99 to 108 |
| | Multiple Termination Connectors | 87 | 109 to 111 |

| CHAPTER 11 | ELECTRIC CONNECTOR SEALING COMPO | UND | |
|------------|--|--|---|
| | Introduction Reference Specifications Description General Precautions Preparation of Sealing Compound Storage of Sealing Compound Preparation of Fluorocarbon Insulated Wire for Potting PR-1547 (MIL-M-24041) Moulding and Potting Compound | 1 1 1 2 3 3 | 1 to 2 3 4 5 to 6 7 to 9 10 to 12 13 to 18 |
| CHAPTER 12 | RF CONNECTORS AND CABLING | | |
| | Introduction Reference Specifications Description General Precautions and Procedures Soldering Coaxial Cable to RF Connectors BNC and TNC Series Connectors C and SC Series Connectors HN Series Connectors N Series Connectors Pulse Series Connectors Miniature RF Connectors Sub-miniature RF Connectors RF Connectors Used in Fuel Quantity Indicating Systems Assembly Procedure for Sub-miniature Connector ONO89558 Assembly Procedure for SMA Termination of Semi-rigid Cable Using Tool M22520/36 Triaxial Connectors | 1 1 1 4 6 7 19 23 26 31 36 38 41 44 | 1 to 2 3 4 to 6 7 to 8 9 to 11 12 to 14 15 to 16 17 to 19 20 to 22 23 to 25 26 to 28 29 to 31 32 to 37 38 to 40 41 to 51 52 to 53 |
| CHAPTER 13 | BONDING AND GROUNDING Introduction Reference Specifications Definitions General Precautions and Procedures Selection of Hardware Preparation of Bonding or Grounding Surfaces Methods of Bonding or Grounding Bonding and Grounding Jumpers Testing Bonds and Grounds Refinishing | 1 1 1 1 2 6 6 8 9 | 1 to 2 3 4 to 6 7 8 to 13 14 to 17 18 to 23 24 to 26 27 to 28 29 |
| CHAPTER 14 | EARTHING AND BONDING OF AIRCRAFT AND GROUND SUPPORT EQUIPMENT Introduction Electrical Grounding for Aircraft Safety Electrical Earthing and Bonding Procedures for Aircraft and GSE Testing Interconnection Leads Aircraft Earthing Receptacle Inspection Procedure Testing GSE Connection Points Ground Earthing Points Testing Ground Earthing Points Mains Operated GSE | 1 1 4 7 10 11 11 12 18 | 1 to 4 5 to 21 22 to 43 44 to 52 53 to 62 63 to 66 67 to 77 78 to 86 87 to 91 |

| CHAPTER 15 | INSTALLATION OF BUSBARS, JUNCTION BOXES, PROTECTIVE DEVICES, AND TERMINAL BOARDS | | |
|------------|--|----------|----------|
| | Introduction | 1 | 1 to 2 |
| | Reference Specifications | 1 | 3 |
| | Preparation and Installation of Busbars | 1 | 4 to 12 |
| | Installation of Junction Boxes | 2 | 13 to 21 |
| | Installation of Protective Devices | 4 | 22 to 42 |
| | Installation of Terminal Boards | 7 | 43 to 50 |
| CHAPTER 16 | THERMOCOUPLE WIRE SOLDERING AND INSTALLATION | | |
| | Introduction | 1 | 1 to 3 |
| | Reference Specifications | 1 | 4 |
| | Description | 1 | 5 to 8 |
| | Definitions | 3 | 9 |
| | Thermocouple Wire Preparation | 3 | 10 to 12 |
| | Hard Soldering Thermocouple Wire | 5 | 13 to 21 |
| | Soft Soldering Thermocouple Wire | 9 | 22 to 27 |
| | Thermocouple Wire Splicing | 11 | 28 to 38 |
| | Mounting AN5537 Connector Assembly | 15 15 | 39 |
| | Routing Thermocouple Wiring | 15 | 40 to 42 |
| CHAPTER 17 | AGED AIRCRAFT WIRING | | |
| | Introduction | 1 | 1 |
| | Definitions | 1 | 2 to 13 |
| | General | 1 | 14 |
| | Handling Aged Wiring | 2 | 15 to 18 |
| CHAPTER 18 | AIRCRAFT ELECTRICAL SYSTEM – INSPEC | CTION | |
| | Introduction | 1 | 1 |
| | Inspection | 1 | 2 to 14 |
| CHAPTER 19 | FIBRE OPTICS | | |
| | Introduction | 1 | 1 |
| | Information | 1 | 2 to 13 |
| INDEX | | | |
| | Alphabetical Index for Section 2 Chapters 1 to 19 | 1 | |

LIST OF TABLES

| Table No | Title | Page No |
|---|---|--|
| SECTION 2 | | |
| CHAPTER 1 | | |
| 1-1 1-2 1-A-1 1-A-2 1-A-3 1-A-4 1-A-5 1-B-1 1-B-2 1-B-3 1-C-1 1-C-2 1-C-3 1-D-1 1-D-2 1-D-3 1-E-1 1-E-2 1-E-3 1-F-4 1-F-5 1-F-6 1-F-7 1-G-1 1-G-2 1-G-3 1-H-1 1-H-2 1-H-3 1-H-4 1-H-5 1-H-6 1-I-1 1-I-2 1-J-1 | Airframe Wire Used In Aircraft Electrical Installations Common Aircraft Wire Insulations Specification Sheets Part Number Coding Conductor Size Conductor Stranding Colour Code Specification Sheets Part Number Coding Wire Size Classification Cable Part Number Breakdown Basic Wire Specification Shield Identification Jacket Identification Preferred Cable Identification Method Optional Cable Identification Method Specification Sheets Part Number Coding Colour Code Equivalent Non-Kapton Insulated Wires Specification Sheets Component Wire Finished Cable Shielded, Jacketed Cable Construction Unshielded, Unjacketed Cable Construction Cable Colour Designation Current Rating of Wires (SAE AS50881) Maximum Allowable Nicked or Broken Strands (SAE AS50881) Wire Gauge Comparison | 3 4 1A-1 1A-2 1A-3 1A-3 1B-1 1B-2 1C-1 1C-2 1D-1 1D-2 1E-1 1F-2 1F-2 1F-2 1F-3 1F-4 1G-1 1H-1 1H-1 1H-2 1H-2 1I-2 1I-1 1I-2 1I-2 |
| CHAPTER 2 | | |
| 2–1 2–2 2–3 | Function and Designation Letters Marking Foil Identification Recommended Sizes of Marking Type | 4 8 8 |

AC 21-99 Aircraft Wiring and Bonding List of Tables

| CHAPTER 3 | | |
|---|---|---|
| 3–1 3–2 3–3 | Allowable Nicked or Broken Strands Identification of Precision Stripper and Blades Approximate Soldering Iron Sizes for Tinning | 2 4 6 |
| 3–4 3–5 | Heat Shrink Solder Sleeves For Tin and Silver Plated Conductors (Splice Temperature rating 150°C) Maximum Heat Shrink Tooling | 8 8 |
| CHAPTER 4 | | |
| 4-1 4-2 4-3 4-4 4-5 4-6 4-7 4-8 4-9 4-10 4-11 4-12 4-13 4-14 4-15 4-16 4-17 4-18 4-19 4-20 | Wire Types Twists Per Foot Bend Radii for Rigid Conduit SAE AMS-DTL-23053/4, Class 2 SAE AMS-DTL-23053/5, Class 1 SAE AMS-DTL-23053/8 SAE AMS-DTL-23053/12 Chloroprene Cushion Clamps Fluorosilicone Cushion Clamps Nitrile Cushion Clamps Cable Clamp Standoff Identification Grommets - Temperature Limitations of Material MS27212 Terminal Boards and Covers Washers for Use with Aluminium Terminal Lugs Installation Torques for Copper Terminal (Inch Pounds of Torque) Installation Torques for Aluminium Terminal (Inch Pounds of Torque) Component Identification Wire Range Accommodations Crimping Tools for TJS Terminals Insulation Repair Tape | 2 3 9 10 10 11 11 14 15 17 18 19 22 22 22 33 33 35 37 |
| CHAPTER 5 | | |
| 5–1 5–2 5–3 5–4 5–5 | Splice Selection Splice Selection Shield Repair Kit Selection Tooling Materials | 2 4 7 9 10 |
| CHAPTER 6 | | |
| 6-1 6-2 6-3 6-4 6-5 6-6 6-7 6-8 6-A-1 | Colour Coding of Copper Terminal Lug Insulation Terminal Lugs and Tooling – High Temperature Wire Gauging Tools Wire Stripping Lengths for Small Copper Terminal Lugs Dies and Gauges for Power Tool MS25441 Stripping Lengths for Aluminium Wire Splices and Tooling – High Temperature Wire Circular Mil Area (CMA) of Wires and Splices MS25036 – Terminal Lug, Crimp Style, Copper, Insulated, Ring Tongue, Bell Mouthed, Type II, Class 1, For 105°C Total Conductor Temperature | 3 3 4 7 8 10 13 13 |
| 6-A-2 | SAE AS7928/1 Terminal Lug, Crimp Style, Copper, Insulated, Ring Tongue, Type II, Class 1, For Thin Wall Wire For 105°C Total Conductor Temperature | 6A-3 |
| 6–A–3 | SAE AS7928/4 Terminal Lug, Crimp Style, Copper, Insulated, Ring Tongue, Bell Mouthed, Type II, Class 1, For 150°C Total Conductor Temperature | 6A–4 |

| 6-A-4 | SAE AS81824/1 Splice, Electric, Permanent Crimp Style, Copper, Insulated, Environment Resistant, Class 1, For 150°C | |
|----------------|---|----------|
| 6-A-5 | Total Conductor Temperature MS25274 Cap, Electrical, Wire End, Crimp Style, Class 1, | 6A–6 |
| | For 105°C Total Conductor Temperature | 6A-6 |
| 6-C-1 | Single Wire In-Line Junctions | 6C-1 |
| 6-C-2 | Double Wire In-Line Junctions | 6C-2 |
| 6–D–1 | Copper Terminal Lugs and Splices (SAE AS7928 and SAE AS81824) | 6D-3 |
| 6-D-2 | Aluminium Terminal Lugs and Splices (SAE AS70991) | 6D-4 |
| 6-D-3 | Electrical Connector Contacts (MIL-C-39029) | 6D–4 |
| CHAPTER 8 | | |
| 8–1 | Tape Lacing and Tying | 2 |
| 8–2 | Self Clinching Cable Straps and Installation Tools | 6 |
| 8–3 | Selection of Spirap | 8 |
| CHAPTER 9 | | |
| 9–1 | Safety Wire - Identification | 2 |
| CHAPTER 10 | | |
| 10–1 | Stripping Lengths for Solder Connections | 4 |
| 10–2 | Insulating Sleeving Material | 5 |
| 10–3 | Heat Shrinkable Tubing Material | 5 |
| 10–4 | Insulating Sleeving/Heat Shrinkable Tubing Sizes | 5 |
| 10–5 | Electrical Contact BIN Code Listing | 12 |
| 10–6 | Specification Replacements | 21 |
| 10–7 | Crimping Tool Inspection Gauges and Selector Settings | 21 |
| 10–8 | Contacts and Their Wire Size Range | 25 |
| 10–9 | Test Leads | 36 |
| 10–10 | Electrostatic Free Dust Caps | 37 |
| 10–11 | Wire End Caps | 40 |
| 10–12 | O-Ring Sizes For AN Type Connectors | 40 |
| 10–13 | Telescoping Bushings (MS3420 – XX) | 44 |
| 10–14 | Selecting MS3057 Cable Clamp | 45 |
| 10–15 | MIL-DTL-83723 Connectors | 50 |
| 10–16 | MIL-DTL-5015 Connector Classes | 53 |
| 10–17 | Miniature MS Connector Type and Class Availability | 60 |
| 10–18 | MIL-C-81511 Connectors | 62 |
| 10–19 10–20 | MIL-C-81511 Contact Insertion and Removal Tools Availability of MIL-DTL-38999 Connectors | 65 68 |
| 10–20 | Installation Torque Values for MIL-C-85049 Circular Electrical | 00 |
| 10-21 | Connector Accessories | 70 |
| 10–22 | MIL-C-81659 Connectors | 75 |
| 10–22 | Contact Insert Arrangements for MIL-C-81659 Connectors | 76 |
| 10–23 | Insert Arrangements, MIL-C-81659 Connector, Series 1 and 2 | 78 |
| 10–25 | Polarization (Keying) Positions | 79 |
| 10–26 | Tools for MIL-C-81659 Standard Contacts | 80 |
| 10–27 | Stripping Lengths, Crimping Tools, Contacts, and Cables for | |
| | MIL-C-81659 Coaxial Connectors | 83 |
| 10–28 | MS27488 Sealing Plugs and Superseded Part Numbers | 87 |

AC 21-99 Aircraft Wiring and Bonding List of Tables

| CHAPTER 11 | | |
|------------|--|--------|
| 11–1 | Shrinkable Tubing | 5 |
| CHAPTER 12 | | |
| 12–1 | BNC & TNC Series M39012 Connectors and Associated Cables (MIL-C-17) | 12 |
| 12–2 | Series C and SC M39012 Connectors and Associated Cables (MIL-C-17) | 19 |
| 12–3 | HN Series Connectors (MIL-C-3643) with Associated Cables | 25 |
| 12–4 | Series N M39012 Connectors and Associated Cables (MIL-C-17) | 28 |
| 12–5 | Pulse Series Connectors (MIL-C-3643) with Associated Cables | 33 |
| 12–6 | MB Series Connectors with Associated Cables | 38 |
| 12–7 | Stripping Dimensions for Coaxial Cable Assembled to | |
| | MB Connectors | 38 |
| 12–8 | Stripping Dimensions and Crimping Tool Positions for | |
| | Subminiature RF Connectors | 39 |
| 12–9 | Stripping Dimensions for Coaxial Cable Assembled to | |
| | Liquidometer S62 and S63 Series Connectors | 43 |
| 12–10 | Crimping Tool Details | 44 |
| 12–11 | Crimping Tool Details | 45 |
| 12–12 | Cable, Connector and Tool Component Selection | 49 |
| 12–13 | Bend Segment Selection | 52 |
| CHAPTER 13 | | |
| 13–1 | Hardwara for Stud Banding or Crounding to Elet Surface | 2 |
| 13–1 | Hardware for Stud Bonding or Grounding to Flat Surface Hardware for Plate Nut Bonding or Grounding to Flat Surface | 3 4 |
| 13–3 | Hardware for Bolt and Nut Bonding or Grounding to Flat Surface | 5 |
| 13–3 | Tinned Copper Woven Braid for Fabrication of Electrical Grounding | J |
| 10 1 | and Bonding Leads | 9 |
| CHAPTER 14 | | |
| 14–1 | Parts List For Interconnection Leads | 9 |
| CHAPTER 16 | | |
| | | |
| 16–1 | Thermocouple System | 2 |
| 16–2 | Thermocouple Terminals | 2 |
| 16–3 | Coding for Thermocouple Contacts in MS Connectors | 4 |
| 16–4 | Code for Markings on AN5537 | 11 |

LIST OF FIGURES

| Figure No | Title | Page No |
|---|---|---|
| SECTION 2 | | |
| CHAPTER 1 | | |
| 1–1 1–2 | Wires Commonly Used In Aircraft Cables Commonly Used In Aircraft | 2 2 |
| CHAPTER 2 | | |
| 2-1 2-2 2-3 2-4 2-5 2-6 2-7 2-8 | Example of ADF Wire Identification Coding Spacing of Identification Marking on Wire and Cable Location of Identification Sleeve Multi-conductor Cable Identification Coaxial Cable Identification Wire Identification at Terminal Board Marking on Sleeves Identification of Wire Bundles and Harnesses | 2 6 6 7 7 7 8 9 |
| CHAPTER 3 | | |
| 3–1 3–2 3–3 3–4 3–5 3–6 3–7 3–8 | Wires After Cutting Wire Cutting Tools Stripping Wire With Hand Stripper Dip-Tinning in Solder Pot Tinning Wire With Soldering Iron Combined Cable Diameter Measurements Solder Sleeve Shield Termination Solder Sleeve Floating Shield Termination | 1 2 4 6 6 7 9 |
| CHAPTER 4 | | |
| 4-1 4-2 4-3 4-4 4-5 4-6 4-7 4-8 4-9 4-10 4-11 4-12 4-13 4-14 4-15 4-16 4-17 4-18 4-19 4-20 | Group and Bundle Ties Staggered Splices in Wire Bundles Slack Between Supports Routing Bundles Cable Clamp at Bulkhead Hole Cable Clamp and Grommet at Bulkhead Hole Drainage Hole in Low Point of Tubing Separation of Wires From Plumbing Lines Capacity Limits for Conduit Preferred Angle for Cable Clamps Typical Mounting Hardware for MS21919 Cable Clamps Attaching Cable Clamp to Structure Tool for Installing Cable Clamp Installing Cable Clamps to Tubular Structure Split Grommet Cutting Caterpillar Grommet Connecting Terminal Lugs to Terminal Board Hardware for Wiring Terminal Boards With Copper Terminals Hardware for Wiring Terminal Boards With Aluminium Terminals | 2 3 4 6 8 8 9 15 16 16 17 17 18 18 20 20 |
| 4-21 4-22 4-23 4-24 | Terminals Connecting Aluminium Terminal to Aluminium Busbar Connecting Copper Terminal to Aluminium Busbar Connecting Aluminium Terminal to Copper Busbar Connecting Copper Terminal to Copper Busbar | 21 23 23 23 24 |

AC 21-99 Aircraft Wiring and Bonding List of Figures

| 4-25 4-26 4-27 4-28 4-29 4-30 4-31 4-32 4-33 4-34 4-35 4-36 4-37 4-38 4-39 4-40 4-41 4-42 4-43 4-44 | Connecting Two Terminals to Same Point on Busbar Insulating Tubing Around Busbar Conduit Capacity Leader for Conduit Support for Wire at Conduit End Installing Conduit on Connector Back Shell Self-Locking Connector Support Inside Junction Box Feedback Terminal Junction Assembly Series I Feedback Terminal Junction Assembly Series I Feedback Terminal Junction Assembly Series II Grounding Junction Assembly Series II Feed-Through Terminal Junction Assembly Series I Removable Contacts and Wire Splices Series I Removable Contacts and Wire Splices Series II Installation and Removal of Modules Components of Terminal Junction System – Series I Components of Terminal Junction System – Series II Contact Insertion in Removable Contact Wire Splices Contact Removal from Removable Contact Wire Splices | 24 25 25 26 26 28 28 29 30 31 31 32 32 33 34 34 36 36 |
|---|---|---|
| CHAPTER 5 | | |
| 5-1 5-2 5-3 5-4 5-5 5-6 5-7 5-8 5-9 5-10 5-11 5-12 5-13 5-14 5-15 5-16 5-17 5-18 5-19 5-20 5-21 5-22 5-23 5-24 5-25 5-26 5-27 5-28 5-29 4-30 | Damage Assessment Removing Damaged Area Sealing Sleeve Placed on One Wire End Correctly Installed Crimp Barrel Sealing Sleeve Centred Over Crimp Barrel Splice Sealing Completed Splices Scored Jacket on Multi-Conductor Cable Damage Assessment Removing Damaged Area Sealing Sleeve Placed on One Wire End Correctly Installed Crimp Barrel Sealing Sleeve Centred Over Crimp Barrel Splice Sealing Completed Splices Taping Cable Jacket Scored Jacket Damaged Multi-conductor Cable Wire With Damaged Section Removed Undamaged Wires Cut at Staggered Locations Tubing and Braid Located on Cable End Jumper Wire Cut to Match Removed Segment Jacket Removed Repair Braid Centred Over Repair Area Heating Repair Braid Tubing Centred Over Repaired Area Single Shield Cable Strip Dimensions Double Shield Cable Strip Dimensions for Mini-Seal Crimp Double Shield Cable Strip Dimensions for Mini-Seal Crimp | 1 1 1 2 2 2 2 2 3 3 3 3 4 4 4 4 4 5 5 6 6 6 6 6 6 6 6 7 8 8 8 8 8 8 8 8 8 8 8 |
| CHAPTER 6 | | |
| 6–1 6–2 6–3 6–4 | Solderless Terminal Lugs and Splices Preinsulated Terminal Lug – Cut-Away Crimp Tools and Dies Proper Insertion of Stripped Wire in Insulated Terminal Lug for Crimping Insulating Sleeves | 2 3 5 7 7 |
| 6–6 | Power Crimping Tools – Large Copper Terminal Lugs | 9 |

AC 21-99 Aircraft Wiring and Bonding List of Figures

| 6-7 6-8 6-C-1 6-C-2 6-D-1 6-D-2 6-D-3 | Positioning Aluminium Terminal Lugs in Die Nests Single Crimp on Aluminium Terminal Lugs Single Wire In-Line Junction Body Double Wire In-Line Junction Body Terminal Lug Splice Connector Contacts | 11 11 6C-1 6C-2 6D-2 6D-2 6D-3 |
|---|--|--|
| CHAPTER 7 | | |
| 7–1 7–2 7–3 7–4 7–5 | Soldering Iron Tip Before and After Cleaning Tinning Soldering Iron Tip Soldering Iron Tip Shapes Correct Solder Application Good and Bad Soldered Connections | 3 3 5 6 6 |
| CHAPTER 8 | | |
| 8–1 8–2 8–3 8–4 8–5 8–6 | Single Cord Lacing Double Cord Lacing Lacing a Branch-off Making Ties Strap Configuration MS90387 Adjustable Hand Tools for Installing Self-Clinching Plastic Tiedown Straps | 2 3 4 4 5 |
| CHAPTER 9 | | |
| 9-1 9-2 9-3 9-4 9-5 9-6 9-7 9-8 9-9 9-10 | Double Twist Lock Wiring Single Wire Method Use of Lock Wire Pliers Lock Wiring Thread Coupled Connector Twisting Method Drilling Hole in Coupling Nut Lock Wiring Connector Using Adel Clamp Lock Wiring Connector to Structure Wiring Split Shell Assembly Screws Shear Wiring Switch Guard | 2 3 3 4 4 4 5 5 6 6 |
| CHAPTER 10 | | |
| 10-1 10-2 10-3 10-4 10-5 10-6 10-7 10-8 10-9 10-10 10-11 10-12 10-13 10-14 10-15 10-16 10-17 10-18 | MS Connector Marking Alternative Positions of Connector Inserts Typical Circular Connectors Insulating Sleeving Installed Over Solder Cup Soldering Iron Tip Shapes Resistance Soldering Pliers For Large Contacts Resistance Soldering Pencil For Small Contacts Torch Soldering Large Contact Soldering Large Size Contacts Soldering Small Size Contacts Soldering Medium Size Contacts Connector Soldering Sequence Insulation Sleeve or Heat Shrinkable Tubing Bottomed Against Insert Preshaping and Tying Wires Contact Marking Typical M22520 Positioner and Turret Head M22520 Crimping Tools Assembling Wires To Crimp Type Contacts | 2 3 4 6 6 7 7 7 8 8 8 9 10 10 23 23 24 |
| 10–19 | Insertion and Extraction Tools for Front Release Crimp Type Contacts | 27 |

AC 21-99 Aircraft Wiring and Bonding List of Figures

| 10-20 10-21 10-22 10-23 10-24 10-25 10-26 10-27 10-28 | Assembling Wired Contacts Into Connector Removing Crimp Type Contacts From Front Release Connectors Insertion and Extraction Tool For Rear Release Crimp Contacts Tweezer Type Installing Tools Single or Double Ended Contact Installing Tools Single or Double Ended Contact Removal Tools Tweezer Type Removal Tools Terminating Shielded Wire at MS Connector Terminating Shielded Wire at Potted Connector | 28 29 30 31 31 32 32 33 33 |
|---|---|--|
| 10–29 | Permanent Splice for Terminating Two Wires at One Contact on Non-environmental Resistant Connector | 34 |
| 10–30 | Reducing Wire Size at Connector Using Permanent Environmental Splice | 34 |
| 10–31 | Installing AN3111 Bonding Ring | 35 |
| 10–32 | Terminating Two Wires to One Contact Using Permanent Environmental Splice | 35 |
| 10–33 | Typical Protective Connector Caps | 37 |
| 10–33 | Spare Wires for Potting Connector | 38 |
| 10–34 | | 39 |
| | Filling and Curing Potting Connector | |
| 10–36 | Installation of O-Ring on AN Type Potted Connector Plug | 39 |
| 10–37 | Cable Clamps | 43 |
| 10–38 | MS3057 Connector Cable Clamp Types – Exploded View | 43 |
| 10–39 | Installation of MS3057 Cable Clamp | 44 |
| 10–40 | Installation of MS3057A Cable Clamp | 45 |
| 10-41 | Installation of MS3057B Cable Clamp | 45 |
| 10–42 | Typical AN(MS) Connectors | 54 |
| 10–43 | Insert Arrangements - AN Type Connectors, MIL-DTL-5015 and | ٠. |
| 10-40 | MIL-DTL-83723, Series II | 55 |
| 10–44 | | 61 |
| | Typical MS Connectors – Miniature | |
| 10–45 | Colour Marking for Individual Release MIL-C-81511 Connectors | 63 |
| 10–46 | Typical MIL-DTL-38999 Connectors | 69 |
| 10–47 | Typical Cable Clamps For MIL-DTL-5015 (MS3400 & MS3450 Series), MIL-C-26482 (Series 2), MIL-C-81703 (Series 3) and MIL-DTL-83723 (Series I and Series II) Connectors | 71 |
| 10–48 | Typical Cable Clamps For MIL-DTL-38999 Series I, II, III & IV Connectors | 72 |
| 10 10 | | |
| 10–49 | Typical MIL-C-81659 Duplex Connector | 76 |
| 10–50 | Assembly of MIL-C-81659 Connectors With Standard Contacts | 76 |
| 10–51 | Assembly of MIL-C-81659 Connectors Polarization (Keying) Posts and Inserts | 80 |
| 10–52 | Assembly of MIL-C-81659 Connectors with Coaxial Connectors | 81 |
| 10–53 | Insertion of Standard Contacts in MIL-C-81659 Connectors | 82 |
| 10-54 | Removal of Standard Contacts in MIL-C-81659 Connectors | 82 |
| 10–55 | Installation of Sealing Boot and Ferrule on Coaxial Cable Before | - |
| | Crimping Contacts | 82 |
| 10–56 | Stripping Dimensions for Coaxial Cable in Table 10–27 | 82 |
| 10–57 | Crimping Centre Contacts with AMP 220015-1 Crimping Tool | 84 |
| | | - |
| 10–58 | Contact Assembly Using Seal Ring | 85 |
| 10–59 | Crimped Centre Contact of Braided Coaxial Cable Inserted in | 85 |
| 10–60 | Contact Body Contact-Ferrule Assembly in Ferrule Crimping Die of Crimping | |
| 10–61 | Tool AMP 220015-1 Ready for Crimping AMP 220066-1 Ferrule Crimping Tool Showing the Three | 85 |
| 10–62 | Crimping Dies Contact-Ferrule Assembly in Crimping Die of AMP 220066-1 | 85 |
| 10–63 | Ferrule Crimping Tool Ready for Crimping Crimped Centre Contact of Semi-Rigid Coaxial Cable Inserted in | 85 |
| 10–64 | Contact Body Semi-Rigid Cable-Contact Assembly in Crimping Die of AMP | 85 |
| 10–65 | 220066-1 Ferrule Crimping Tool Ready for Backshell Crimping Insertion of Rear-Release Coaxial Contacts in MIL-C-81659 | 86 |
| 10-00 | Connectors | 86 |

| 10–66 | Removal of Rear-Release Coaxial Contacts From MIL-C-81659 Connectors | 86 |
|----------------|---|----------|
| 10–67 | Multiple Termination Connector | 88 |
| 10–68 | Inspection Criteria | 89 |
| CHAPTER 12 | | |
| 12–1 | RF Connectors | 2 |
| 12–2 | Typical BNC Connectors | 3 |
| 12–3 | Typical HN Connectors | 3 |
| 12–4 | Typical N Connectors | 3 |
| 12–5 | Typical C Connectors | 3 |
| 12–6 | Typical Pulse Connectors | 4 |
| 12–7 | Typical TNC Connectors | 4 |
| 12–8 | Typical SC Connectors | 4 |
| 12–9 | Typical Coaxial Cables | 4 |
| 12–10 | Tinning Centre Conductor | 5 |
| 12–11 | Tinning Inside of Contact | 5 |
| 12–12 | Soldering Contact to Coaxial Cable | 6 |
| 12–13 | Tightening Braid Clamp Nut into Plug or Jack Body | 6 |
| 12–14 | Correct Shape for Soldering Iron Tip | 6 |
| 12–15 | Attaching BNC & TNC (M39012) Crimp Connectors to Coaxial Cable | 8 |
| 12–16 | M22520/5-01 Crimping Tool and Hex Dies | 9 |
| 12–17 | M22520/5-01 Crimping Tool and Turret | 10 |
| 12–18 | M22520/5-01 Crimping Tool Turrets | 11 |
| 12–19 | Attaching Improved BNC Connectors to Coaxial Cable | 17 |
| 12–20 | Attaching BNC Connectors With Captivated Contacts to Coaxial Cable | 18 |
| 12–21 | Attaching Series C and SC Connectors to Coaxial Cable | 19 |
| 12–22 | Cable Crimping Instructions | 23 |
| 12–23 | Improved HN Connectors - Exploded View | 25 |
| 12–24 | HN Connectors with Captivated Contacts - Exploded View | 25 |
| 12–25 | Attaching Improved HN Connectors to Coaxial Cable | 26 |
| 12–26 | Attaching HN Connectors with Captivated Contacts to Coaxial Cable | 26 |
| 12–27 | N Crimp Connectors | 26 |
| 12–28 | Cable Stripping Instructions | 27 |
| 12–29 | Attaching N Connectors with Captivated Contacts to Coaxial Cable | 31 |
| 12–30 | Pulse Connector – Ceramic Insert | 32 |
| 12–31 | Pulse Connector – Rubber Insert | 32 |
| 12–32 | Assembly of Ceramic Insert Pulse Connector | 34 |
| 12–33 | Assembly of Rubber Insert Pulse Connector | 36 |
| 12–34 | MB Connectors - Exploded View | 37 |
| 12–35 | Attaching MB Connectors to Coaxial Cable | 37 |
| 12–36 12–37 | Subminiature RF Connector - Exploded View | 39 40 |
| 12–38 | Attaching Subminiature RF Connectors to Coaxial Cable Crimping Subminiature RF Connectors | 40 |
| 12–39 | Attaching Avien 163-088 and 163-089 Connectors to Coaxial Cable | 41 |
| 12–40 | Attaching Avien 163-088 and 163-089 Connectors to Unshielded Wire | 41 |
| 12–41 | Attaching Liquidometer 9100 Series Connectors to Coaxial Cable | 42 |
| 12–42 | Attaching Nu-Line 1200 Series Connectors to Coaxial Cable | 43 |
| 12–43 | Attaching Liquidometer S62 and S63 Series Connectors to Coaxial | 40 |
| 12 10 | Cable | 44 |
| 12–44 | Stripping Dimensions, Scaling Boot, Ferrule and Contact Before Crimping the Contact | 45 |
| 12–45 | Final Assembly and Outer Ferrule Crimping | 45 |
| 12–46 | Crimping Tool for Shielded Outer Ferrule | 46 |
| 12–47 | Final Connection Assembly | 46 |
| 12–48 | Stripping Dimensions and Sealing Boot Before Crimping the | |
| | Contact | 46 |
| 12–49 | Assembly Before Crimping | 47 |
| 12–50 | Final Assembly and Outer Ferrule Before Crimping Outer Ferrule | 47 |

AC 21-99 Aircraft Wiring and Bonding List of Figures

| 12–51 12–52 12–53 12–54 12–55 12–56 12–57 12–58 12–59 12–60 12–61 12–62 12–63 12–64 12–65 12–66 12–67 12–68 | Assembly of Dage Type Connectors SMA Connectors M39012, Category F Tooling to Prepare Semi-rigid Cable Pointing the Cable End Termination Tooling Locator and Locking Screw Orientation of Die Chambers Die Alignment Plug Termination Jack Termination Radii Dimensions for Semi-Rigid Cable Bending Spacer on Dummy Jack 0.025 Inch Radius Bends on RG-402/U Cable and 0.125 Inch Radius Bends on RG-405/U Cable 0.125 Inch Radius Bends on RG-402/U Cable Triaxial Connector Assembly - Exploded View Attaching Triaxial Connector to Cable Attaching Gasket to Middle Insulation Attaching Outer Shell to Gasket | 48 49 50 50 51 52 52 52 53 53 54 54 55 56 56 |
|--|--|--|
| CHAPTER 13 | | |
| 13–1 13–2 13–3 13–4 13–5 13–6 13–7 13–8 | Stud Bonding or Grounding to Flat Surface Plate Nut Bonding or Grounding to Flat Surface Bolt and Nut Bonding or Grounding to Flat Surface Stainless Steel Wire Brush With Pilot for Cleaning Aluminium Surfaces Bonding Tab Riveted to Structure Aluminium Jumper Connection to Tubular Structure Copper Jumper Connection to Tubular Structure Bonding Conduit to Structure | 3 4 5 6 7 8 8 8 |
| CHAPTER 14 | | |
| 14-1 14-2 14-3 14-4 14-5 14-6 14-7 14-8 14-9 14-10 14-11 14-12 14-13 | Mobile (Self Contained) Aircraft External Power Supply Mobile Rectifier/Frequency Converter Aircraft External Power Supply Reticulated Aircraft External Power Safety Interconnection Lead (Configuration 1) Safety Interconnection Lead (Configuration 2) Safety Interconnection Lead (Configuration 3) Safety Interconnection Lead (Configuration 4) Suggested Format for Test and Inspection Log Standard Earth Reference Point Temporary Earth Reference Point Earth Reference Point Test Setup for GEOHM Type Testers Suggested Format for Test and Inspection Log Helicopter Earthing Pole | 3 3 7 8 8 8 10 13 14 15 16 |
| CHAPTER 15 | | |
| 15–1 15–2 15–3 15–4 15–5 15–6 15–7 15–8 15–9 15–10 | Scratch Brushing Unplated Aluminium Alloy Busbars Mounting Busbars to Structure Attaching Junction Box to Structure Attaching Cover to Junction Box Wire Entry Holes in Junction Box Mounting Protective Devices Typical Mounting Hardware for Protective Devices Determining Screw Length for Mounting into Blind Holes Circuit Breaker Lockout Ring Mounting of Terminal Board Alternative Mounting of Terminal Board | 3 4 4 5 5 6 6 6 7 8 8 |

AC 21-99 Aircraft Wiring and Bonding List of Figures

| 15–12 | Insulation of Terminal Board | 8 |
|--------------|--|--------|
| 15–13 | Identification of Terminal Board | 9 |
| CHAPTER 16 | | |
| 16–1 | Thermocouple Wire | 2 |
| 16–2 | Thermocouple Terminals | 3 |
| 16–3 | Thermocouple Connector Assembly (AN5537) | 4 |
| 16–4 | Stripping Thermocouple Wire for Terminal and for AN5537 Connector Installation | 4 |
| 16–5 | | 4 |
| 16–5 16–6 | Stripping Thermocouple Wire for Splice Installation | 4 |
| 16–7 | Stripping Thermocouple Wire for MS Connector Installation Torch Tinning Thermocouple Wire | 5 5 |
| 16–7 16–8 | Dip Tinning Thermocouple Wire in Silver Solder | 6 |
| 16–9 | Resistance Heating to Tin Wire | |
| 16–10 | Resistance Tinning of Terminal | 6 7 |
| 16–10 | Silver Soldering Thermocouple Wire to Terminal | 7 |
| 16–12 | Modified Crimping Tool for Thermocouple Terminals | 8 |
| 16–12 | Reinforcing Solder on AN5539 Terminals | 8 |
| 16–14 | Serving Thermocouple Wire | 9 |
| 16–15 | Torch Soldering Thermocouple Wire to MS Connector Contact | 10 |
| 16–16 | Butt Splicing Procedure | 13 |
| 16–17 | Stub Splicing Procedure | 14 |
| 16–18 | Distributing Slack in Thermocouple Wire | 15 |
| 10 10 | Bloanbatting Glack III Thorntocouple Wile | |
| CHAPTER 19 | | |
| 19–1 | Typical Fibre Optic Cable Construction | 1 |
| 19–2 | Loss Due To End Separation | 1 |
| 19–3 | Loss Due To Lateral Displacement | 2 |
| 19_4 | Loss Due To Angular Displacement | 2 |